



mounting instructions
Triumph Classic Skid Plate (308515)



Installation time : 25 minute

Tools requirement:
1) Allen wrench 4 mm.
3) Open-end box 8-10 mm.
4) Scissor
4) Heat Gun



1



Remove bolts as photo
The highlighted bushings are reused.



2



Cut half the neoprene adhesive.
Apply neoprene as photos.



3

Insert the washers m6 shnoor.
 Insert two buttonhead bolts M6 x 50 TBCE, spacers and OEM bushings.



4

Insert shrink tube on brackets.



5

Place skid plate and secure the front side.



6

Insert brackets as photo



7

Attach the bottom.

